

STAR CONSTRUCTION — HULL LAYOUT

(Deck Removed)

BRASS TUBE FOR JIB SHEET.

THE TWO TUBES ARE 1/8" O.D. AND BENT IN A TWISTED "S" SHAPE.

THEIR PURPOSE IS TO GUIDE THE SHEETS UNDER THE DECK TO THE FAIRLEADS. THIS PERMITS EASY RESTRINGING WHEN NECESSARY.

ALL DIMENSIONS SHOWN BELOW ARE TAKEN FROM THE BOW POINT.

FWD. PULLEY

TRAVELER

JIB FAIRLEAD 14 1/2"

MAST AND UPPER SIDE STAYS

17 1/2"

FWD. BULKHEAD 18 3/4"

MAIN SHEET PASSES THRU THIS PULLEY AND THRU TRAVELING PULLEY AND TIES OFF ON THE FWD. BULKHEAD.

JIB SHEET TIES DIRECTLY TO PULLEY.

TRAVELING PULLEY =====
APPROX. 18" OF TRAVEL

AFT. PULLEY

TRAVELER

AFT. BULKHEAD 37 3/8"

RUDDER POST 39"

MAIN SAIL FAIRLEAD 40 1/2"

BRASS TUBE FOR MAIN SHEET