

STAR CONSTRUCTION – WINCH/PULLEY ASSEM.

ASSEMBLE THE WINCH AND PULLEYS AS SHOWN ON THE FOLLOWING PAGE.

INSTALL THE LINE AS FOLLOWS:

- 1) USE 50 lb. BRAIDED BAIT CASTING LINE.**
- 2) CUT OFF A 6' LENGTH**
- 3) USING THE RADIO, RUN THE SPOOL TO THE "SAILS FULL OUT" POSITION.**
- 4) PASS ONE END OF THE LINE THRU THE HOLE IN THE SIDE OF THE SPOOL AND PULL THE LINE THRU AND MATCH THE ENDS TOGETHER. (THERE WILL NOW BE TWO LINES EACH 3' LONG.)**
- 5) WRAP ABOUT 2 TURNS OF THE LINE AROUND ONE SIDE OF THE SPOOL AND ,USING THE RADIO, RUN THE SPOOL TO THE FULL "SAILS IN" POSITION. THE LINE WILL WRAP ONTO THE SPOOL. THE LOOSE END OF THE LINE SHOULD COME OFF THE TOP OF THE SPOOL AND POINT TO THE REAR OF THE BOAT.**
- 6) PASS THIS LINE THRU THE PULLEY ATTACHED TO THE AFT BULKHEAD. (FROM THE BOTTOM UP.)**
- 7) TIE ON THE TRAVELING PULLEY AS CLOSE TO THE REAR PULLEY AS POSSIBLE. (BE SURE TO GLUE THE KNOT.)**
- 8) USING THE REMAINING 3' OF LINE, WRAP ABOUT 2 TURNS AROUND THE OTHER SIDE OF THE SPOOL. MAKE SURE THAT THE LINE COMES OFF THE TOP OF THE SPOOL AND POINTS TOWARD THE BOW.**
- 9) RUN THE LOOSE END THRU THE SPRING PULLEY AND UP AND THRU THE PULLEY ATTACHED TO THE FWD. BULKHEAD.**
- 10) PASS THIS LINE THRU THE TRAVELING PULLEY AND PULL IT TIGHT ENOUGH TO STRECH OUT THE SPRING AND KNOT IT.**